



Delivery pump GML-A 105.220

EUGEN WOERNERGmbH & Co. KGPostfach 1661DE-97866Am Eichamt 8DE-97877Tel. +49 (0) 9342 803-0info@woerner.deFax.+49 (0) 9342 803-202www.woerner.de

Replaces No. 0102.06.04 EN Page 1 of 3

Leaflet-No.

0102.11.06 EN

- Subject to modifications





### Mode of operation:

The delivery pump consists of a piston pump, an electric magnet, and a reservoir. **Suction phase:** 

The pistons are set back by means of spring force. As a result, the lubricant is sucked in from the reservoir by virtue of the partial vacuum generated.

# Pressure phase:

Upon actuation of the electric magnet, the pistons start to deliver the lubricant to the outlets.

# Venting:

In order to ensure a steady delivery, the delivery pump needs to be vented. To this effect, the electric magnet is to be activated as often until the lubricant comes out at all outlets.

In case of cartridge exchange, the vent plug "B" should be opened until the lubricant comes out free of air inclusions.

#### Delivery pressure:

The maximum possible delivery pressure depends on the electric magnet, the number of outlets and the lubricant.

Outlets	Delivery pressure	
(Variant)	Magnet "A"	Magnet "C"
1	appr. 20bar	appr. 60bar
2	appr. 10bar	appr. 30bar
2A; 3	appr. 7bar	appr. 20bar
4	appr. 5bar	appr. 15bar



### Purchase-example:

Delivery pump GML-A, outlets 2x30mm<sup>3</sup>, outlet connector ALL, reservoir 0,5I, without delivery and filling level control, 100% ED, 24VDC.

#### **Purchase-designation:**

# Delivery pump GML-A/2/A/B/0/A/G1

- <sup>1)</sup> Electric magnets with special voltage available upon request
- <sup>2)</sup> without electric magnet (spare part)

EUGEN WOERNERGmbH & Co. KGPostfach 1661DE-97866Am Eichamt 8DE-97877Tel. +49 (0) 9342 803-0info@woerner.deFax.+49 (0) 9342 803-202www.woerner.de

0102 EN

Leaflet-No.

Page 2 of 3



### Filling the cartridge reservoir:



#### Caution!

After having screwed the reservoir on, release projecting piston bar and push it into the reservoir by applying thumb pressure on clamping lever.



 EUGEN
 WOERNER
 GmbH
 & Co. KG

 Postfach
 1661
 DE-97866
 Wertheim

 Am
 Eichamt
 8
 DE-97877
 Wertheim

 Tel.
 +49 (0) 9342 803-0
 info@woerner.de
 Fax.+49 (0) 9342 803-202
 www.woerner.de

Leaflet-No. 0102 EN

Page 3 of 3